

EUROGOAL 600

SOCCER BALL SHOOTING MACHINE

GLOBUS EUROGOAL 600 IS A PROFESSIONAL BALL SHOOTING TRAINING MACHINE WHICH ALLOWS TO PERFORM WITH EXTREME REALISM CROSSES, SHOTS AND THROWS TYPICAL OF THE GAME OF FOOTBALL, WITH BALL SPEED REACHING UP 110 KM/H. THANKS TO A SPECIAL DEVICE, THE COACH CAN ADJUST THE THROW ON THE VERTICAL PLANE (UPWARDS OR DOWNWARDS), TO MAKE GROUND SHOTS AT HALF HEIGHT OR AT THE CROSSING OF THE POSTS.

GLOBUS EUROGOAL 600 IS THE IDEAL PARTNER FOR GOALKEEPERS AND SOCCER PLAYERS. IT LENDS ITSELF TO BEING USED IN GLOBAL PLAY SITUATIONS, AS CROSS-KICK CONSTRUCTIONS AND CORNER-KICKS.

TECHNICAL SPECIFICATIONS

Dimensions (WxDxH)

95x70x60 cm

Weight

90 Kg

Spinning wheels

2, antiwear supergrip rubber

Maximum throwing height

25 m

Vertical inclination

+40°/-5°

Throwing distance

60 m

Throwing speed

From 10 to 120 Km/h

Power supply

Long-lasting double battery pack (5 actual hours or 1500 throws) with the included charger

Batteries

2 batteries, 12V - 55Ah

Throwing effects

Floating - Magnus

Electric actuator for vertical elevation

Control unit

Manual regulation by means of two independent potentiometers

STRONG POINTS

- No ball damage - GLOBUS patent
- Powerful kicks and spin shots, both in swinging and out swinging, from the right and from the left
- Extremely accurate and independent adjustment of the speed of both wheels (999 levels)
- Compatible with balls of different size
- Easy to move on the wheels
- Instructions for inserting the balls to repeat the shots as best as possible
- Suggested for youth sectors and soccer schools



EUROGOAL 600

SOCCER BALL SHOOTING MACHINE

Rev. En_04_2021